



## How to Figure Net Free Area for Rectangle/Square Vents

$$\text{NFA} = (\text{Width} - 7.12) \times (.70) \times (\text{Louvers} - 1)$$

EXAMPLE: 34" (W) x 42" (H) Vent

34.00	Outside width
<u>-7.12</u>	Ring & frame width
26.88	Width of one louver (air flow opening)
26.88	
x .70	Height of one air flow opening
<u>18.82</u>	Area of one air flow opening (in sq. in.)
16	Number of louvers
<u>-1</u>	Uppermost louver does not provide air flow
15	
18.82	Area of one air flow opening (in sq. in.)
<u>x 15</u>	Number of air flow openings
282.30	Net free area (in sq. in.)



All dimensions are from outside of ring to outside of ring

Customer Service — 800.521.8486  
midamericacomponents.com